




Product Instruction Manual

# Holster Style



**HD190I**

1.4kW automatic hair dryer

Thank you for purchasing the HDI90I Holster style hair dryer. The HDI90I is designed for hotels and similar light commercial applications. This hair dryer is not suitable for heavy usage applications such as public swimming baths and sports facilities. Please read and understand these instructions before commencing installation and leave them with the user when installation is complete.




## 1. Important safety points

- The Electrical installation must be carried out by a qualified electrician in accordance with the current edition of the I.E.E Wiring Regulations.
- Means for electrical disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- Only connect the hair dryer to single phase supply with a mains voltage as specified on the rating plate.
- The hair dryer must be fixed out of reach of a person taking a bath or shower
- The appliance must be fixed so that the hand-held part, when fully extended, is out of reach of a person taking a bath or shower.
- This appliance can be used by children aged from 8 years and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Do not block the air inlet grilles on the hair dryer as this may cause overheating.

## 2. Installation

### Wall mounting

- The appliance must be fixed so that the hand-held part, when fully extended, is out of reach of a person taking a bath or shower.
- Drill 3 holes as per the picture and using the fixings provided insert 2 wall plugs and 2 screws into holes A.
- Remove the cover from the wall mounting plate by removing the 2 screws.
- Hang the mounting plate on the 2 screws using the key hole slots on the mounting plate.
- Secure the appliance by screwing the last screw in B.
- Ensure the mounting plate cover is replaced and secure.



## Electrical

- Means for electrical disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- This unit is double insulated, the power cord should be connected following the coding below:
  - Brown: L
  - Blue: N

## 3. Operation

This appliance has a switch to be pressed continuously during use and a three position switch for three different temperatures.

On the mounting plate there is also a power on/off switch.

To operate the hair dryer:

- Ensure the power switch on the mounting plate base is switched to the on position.
- Select the required temperature setting on the hand held part of the dryer (0.5kW, 1.0kW & 1.4kW)
- Operate the spring loaded switch to turn on the hair dryer. Operation will cease once the switch is released.



## **4. Maintenance**

Before carrying out any cleaning of the product, ensure that the power switch on the mounting plate base is switched to the O position.

Clean the exterior of the unit using a soft damp cloth.

## 5. Specifications

<b>Voltage</b>	<b>230V~50Hz</b>
<b>Max Power</b>	<b>1.4kW</b>
<b>Weight</b>	<b>2.3kg</b>



## **6. Guarantee and service policy**

This product is guaranteed against faulty materials and manufacture for a period of one year from the date of purchase. Hyco will in its sole discretion replace, repair or refund any faulty unit. Incorrect installation and failure to follow correct operating instructions are excluded. Consequential costs such as labour charges or damage to surroundings are expressly excluded.



INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH THE EUROPEAN DIRECTIVE 2002/96/E.

At the end of its working life this equipment must not be disposed of as household waste. It must be taken to a local authority waste collection centre or to a dealer providing this service. Disposing of electrical and electronic equipment separately enables its components to be recovered and recycled to obtain significant savings in energy and resources. In order to underline the duty to dispose of this equipment separately, the product is marked with a crossed out dustbin.

Hycos Manufacturing Ltd  
Normandy Court  
Express Way  
Castleford, WF10 5NR

T 01924 225 200  
F 01924 225 210  
E [sales@hycos.co.uk](mailto:sales@hycos.co.uk)

\* 2725 \*

[hycos.co.uk](http://hycos.co.uk)